

ILME 'MIXO' Inserts

1. Join the modules using the special swallow-tailed guide rails, in order to obtain the wished combination (2, 3, 4 and 6 modular units)
2. Enter the modules combination into the suitable frame. The polarization assures the correct entrance of the combination. The reference arrow, marked on modules and on frame back, must have the same direction
3. Divide the lock-in tabs for frames of 2, 3 and 4 modules. Lock-in tabs have the length of 6 modules frames.
Important: packages of frames for 4 or 6 modules contain one spare lock-in tab for each frame: while in packages of frames for 2 or 3 modules, the spare elements are given by the unused parts of lock-in tabs
4. Enter the lock-in tabs in the suitable place in order to block the modules in the frame

