




TEEPLUG® Plug-and-Socket Connectors Installation Instructions



TH384 / TH385 Series




Panel mount illustrated below (M25 for THB.385.A1A, M20 for THB.385.A3F)







TEEPLUG® Plug-and-Socket Connectors Installation Instructions



Disconnect Power





TH387 Series





TEEPLUG® Plug-and-Socket Connectors Installation Instructions





TH405 Series



Unlock insert using the key



Insert and turn using the key



TEEPLUG® Plug-and-Socket Connectors Installation Instructions



Disconnect Power

TH406 Series

