

JOKARI[®] Dismantling Tools

How to operate the Dismantling Tools by Jokari®

- 1. Adjust the blade cutting depth by turning the red adjustment screw
- 2. Press tool against cable as shown, exerting light pressure with your thumb
- 3. Rotate to execute one or two circular cuts
- 4. Pull tool in direction of arrow to execute a longitudinal cut
- 5. Peel off the sheathing



Step 2

Step 3



Step 5

Printed in Canada: 17-07

ITC Electrical Components



Step 4





Tel: 416-663-7223