



JOKARI[®] Dismantling Tools

How to operate the Dismantling Tools by Jokari[®]

1. Adjust the blade cutting depth by turning the red adjustment screw
2. Press tool against cable as shown, exerting light pressure with your thumb
3. Rotate to execute one or two circular cuts
4. Pull tool in direction of arrow to execute a longitudinal cut
5. Peel off the sheathing



Step 1



Step 2



Step 3



Step 4



Step 5